

## BMZ Hyperion Compatibility Overview

Firmware Rev.: 4.22.R

released CW21 2024

Housing Article No.	Module		Compatibility					
	Article No.	Type	SMA SBS <sup>(1)</sup>	SMA STP SE <sup>(2)</sup>	Kostal <sup>(3)</sup>	GoodWe <sup>(4)</sup>	SOFARSOLAR <sup>(6)</sup>	Solis <sup>(7)</sup>
41871	37832-02	Helios 1.5	3.7 / 5.0 / 6.0	./.	./.	./.	./.	./.
611280	37832-02	Helios 1.5	3.7 / 5.0 / 6.0	./.	./.	./.	./.	./.
615424	37832-02 <sup>(5)</sup> 612033, 626896 <sup>(5)</sup>	Helios 1.5 Helios VE	3.7 / 5.0 / 6.0	./.	./.	./.	./.	./.
610853	612033, 626896	Helios VE	./.	./.	PLENTICORE plus/BI	./.	./.	./.
609678	612033, 626896	Helios VE	./.	./.	PLENTICORE plus/BI	./.	./.	./.
616038	612033, 626896	Helios VE	3.7 / 5.0 / 6.0	5.0 / 6.0 / 8.0 / 10.0	PLENTICORE plus/BI	ET PLUS+ Series	HYD/ME TL-3PH Series	S6-EH3P(3-10)K-H-EU S6-EH3P(12-20)K-H
629779	628899	Helios VE Long Life	3.7 / 5.0 / 6.0	5.0 / 6.0 / 8.0 / 10.0	PLENTICORE plus/BI	ET PLUS+ Series	HYD/ME TL-3PH Series	S6-EH3P(3-10)K-H-EU S6-EH3P(12-20)K-H

<sup>(1)</sup> Sunny Boy Storage Firmware version 0.03.15.R or newer - min. 3 modules

<sup>(2)</sup> Sunny Tripower SE Firmware version 3.02.20.R or newer - min. 4 modules

<sup>(3)</sup> PLENTICORE plus G2 inverters - requires an activation code from Kostal for using a Hyperion - min. 3 modules

<sup>(4)</sup> ET PLUS+ Series (5-10 kW) with inverter ARM firmware version: V20 or higher version - min. 4 modules

<sup>(5)</sup> In one Hyperion either only 37832-02 (Helios 1.5) or only 612033 (Helios VE) should be used

<sup>(6)</sup> HYD 5K...20KTL-3PH and ME 5K...20KTL-3PH series with firmware V110022 or higher version - min. 4 modules

<sup>(7)</sup> S6-EH3P(3-10)K-H-EU and S6-EH3P(12-20)K-H with inverter firmware V04-13 or higher version - min. 3 modules